

GAMA SONIC[®]

SOLAR LIGHTING



ECLIPSE DOWNLIGHT SOLAR WALL LIGHT

Part #: 56iM50010

 Please read the instruction manual carefully to obtain the best results from your purchase.

Thank you for your purchase! GAMA SONIC® solar charged lights are brighter and last all night with a typical solar charge. Unique design, superior light output and numerous installation options confirm the outstanding value of our product. GAMA SONIC® has been recognized as a worldwide leader in the lighting industry for over 20 years.

Technical Assistance/Warranty Claims/Replacement Parts
Toll Free Number: +1-800-835-4113 (only within the US) or www.gamasonic.com

Visit our website or download the latest version of your instruction manual:
www.gamasonic.com




Solar Lamp Location

For optimum light duration throughout the night, it is very important to mount your solar lamp in a spot where it will receive the maximum amount of direct sunlight throughout the day


For best results, the solar light must be charged in the “ON” (High or Low) position for at least 2 days of full direct sunlight.

What's In The Box

A = Light Fixture




Screws x2
with Anchors



Assembly Instructions


NOTE: The following steps are for reference only. Consult your local hardware store for the best installation method for your specific surface.

- Separate the light housing unit and solar panel unit by loosening the four screws on the sides of the fixture and unplug the solar panel wire.



- Use the center of the two mounting holes in the light housing unit as a guide to drill two holes no larger than the anchors and insert the wall anchors.
- Align the wall anchors with the holes on the light housing unit and partially install a screw into the left mounting hole first, then align and level the fixture with the right hole before tightening both screws to secure it to the wall.

NOTE: The LEDs should be facing downward at the bottom of the fixture, as intended for proper illumination.



- Replug the solar panel wire and align the solar panel unit screw slots with the light housing unit screws and secure them together using the four screws you loosened.

NOTE: Do not over-tighten the screws to avoid damage.

Operation Instructions

- Move the operation switch to the High or Low position according to your preferences:

Low = softer light, longer duration


High = brighter light output

- Turn the color temperature to your desired preference:

Warm = 3000K warm white

Soft = 4000K daylight

Cool = 5000K bright white



Replacement Parts

Replacement Batteries are available at www.gamasonic.com or via our Toll Free number: +1-800-835-4113.

Your lamp uses two of the following battery:
GS32V30




Replacing the Batteries

GAMA SONIC®
SOLAR LIGHTING

After several years of use, the battery may need replacing.

1. Switch the unit to the OFF position.
2. Separate the light housing unit and solar panel unit by unscrewing the four screws on the sides of the fixture and unplug the solar panel wire.
3. Unscrew the four screws on the battery compartment door and remove the cover.
4. Unplug the connector and remove the old batteries.
5. Make sure the new batteries are a high-quality Li-Ion battery with matching connector, Part# GS32V30.
6. Clip in the new batteries and install the batteries in the compartment.
7. Reassemble the lamp by reversing steps 1-4



Batteries are available for purchase at www.gamasonic.com

MAINTENANCE

Clean the solar panels regularly with a damp towel to guarantee optimum performance. Do not use any type of solvent for cleaning and be careful not to put too much pressure on the solar panels while cleaning.

TROUBLESHOOTING

If your solar light does not come on as expected despite observance of all the instructions, please try the following steps:

1. Make sure that the solar lamp is not being affected by any other light source.
2. Ensure the solar lamp is not positioned in the shade during the day.
3. Check that the batteries are installed correctly.

NOTE: The performance of the solar lamp will vary with the time of year. It will last longer when it has had a full day in the sun rather than a day in overcast weather.



WINTERTIME TIPS: For optimal performance, be sure to remove any snow or debris accumulation from solar panel(s). A solar panel free of debris will charge the batteries much more efficiently.



WARNING: Please keep out of reach of children. Do not dispose of Li-Ion battery in the regular trash, municipal waste stream or by fire as batteries may leak or explode. Do not open, short circuit, or mutilate batteries as injury may occur. Preserve our environment by recycling Li-Ion batteries or disposing of them in accordance with local, state and federal regulations. Do not mix old and new batteries.

