

GAMA SONIC® SOLAR LIGHTING



PLANTER

EZ ANCHOR

PLANTER AND
EZ ANCHOR



Aspen Solar Lamp Post with Planter & EZ Anchor (3 mounting options)

Part #: M132955 012 / M132955 032 / 8B50051 / 8B50151

 Please read the instruction manual carefully to obtain the best results from your purchase.

Thank you for your purchase! GAMA SONIC® solar charged lights are brighter and last all night with a typical solar charge. Unique design, superior light output and numerous installation options confirm the outstanding value of our product. **GAMA SONIC®** has been recognized as a worldwide leader in the lighting industry for over 20 years.

Technical Assistance / Warranty Claims / Replacement Parts
Toll-Free number: +1-800-835-4113 (only within the US) or www.gamasonic.com

Visit our website or download the latest version of your instruction manual:
www.gamasonic.com or www.gamasonic.com/user-guides

Gama Sonic's Bulb Technology

Gama Sonic's patented Bulb technology gives your solar lamp the look and feel of a traditional incandescent lamp. This helps to distribute light further than traditional solar lamps.

This solar lamp also includes an optional Solar Flame Style LED Light Bulb. This innovative bulb emits a flame-like flickering glow, creating a warm and inviting ambiance while still providing ample visibility for your outdoor space.


Solar Light Location

For optimum light duration throughout the night, it is very important to mount your solar lamp in a spot where it will receive the maximum amount of direct sunlight throughout the day.

NOTE: For best results, the solar light must be charged in the "High or Low" position for at least 2 days of full direct sunlight.



What's In The Box



Assembly Instructions

1. If installing the lamp using the EZ Anchor, position the Auger (K) where you want the lamp to be. (If installing without the anchor, skip to step 5a)
2. Using the turning bar (L), turn the Auger (K) into the ground clockwise. **Note:** For areas with hard dirt, moisten the ground with water to make installation easier.
3. Make sure the Auger goes in straight by using the level bubble at the top. Stop once the metal ring is flush with the ground.
4. If using the Planter (J), place it over the Auger bit.
5. Secure the Lower Pole section (H) according to your intended use:

a. Planter Only (No EZ Anchor)

- Screw Lower Pole section (H) into the bottom of the planter (J).
- Place rocks or stones in the base of the planter (J) to weigh the planter base down and prevent the lamp from tipping over in the wind.
- Place wire net (I) over the Lower Pole (H) so it is sitting at the top of the planter.

b. Planter with EZ Anchor

- Screw Lower Pole section (H) into the bottom of the planter (J).
- Tighten the two screws (H) at the base of the pole using the included tool.
- Place wire net (I) over the Lower Pole (H) so it is sitting at the top of the planter.


c. No Planter (EZ Anchor Only)

- Place the Lower Pole section (H) over the exposed section of the Auger (K) and tighten the two screws (H) at the base of the pole using the included tool.
6. Assemble the rest of the pole by screwing together the couplers (E) and the poles (F).
 7. Attach the fixture (B) to the centerpiece (D) by twisting clockwise.
 8. Attach the centerpiece (D) to the last coupler (E) at the top of the pole by twisting clockwise.
 9. Remove the top (A) from the fixture (B) by removing the four screws.
 10. Insert the GS Solar LED Bulb into the top (A) by twisting clockwise. Be sure to hold the bulb by its base and not the glass.
 11. Turn the lamp on and secure the top (A) to the fixture (B) using the screws removed earlier.

Operation Instructions

1. Turn the external operation switch to the Low or High position
2. According to your preferences:
 - a. Low: For softer light and longer duration.
 - b. High: For brighter light output.
3. The solar lamp will automatically operate at dusk.

NOTE: If there is a film covering the solar panel, make sure to remove this by peeling it off.



Replacement Parts

**Replacement Batteries and Bulbs are available at
www.gamasonic.com or via
our Toll Free number: +1-800-835-4113**

Your Lamp can use the following bulbs:

- A50WW10W – included bulb with Warm White LEDs (2700K)
- A50BW10W – bulb with Bright White LEDs (6000K)
- F30WW05W – included Flame bulb with simulated flame LEDs
- T45WW10W – Edison LED Bulb with Warm White LEDs (2700K)


Your Lamp uses two of the following battery:
GS32V15



Replacing the battery

After several years of use, the battery may need replacing.

1. Make sure the ON/OFF switch is in the “OFF” position (0).
2. Unscrew the four screws on the underside of the lamp top to detach it from the lamp.
3. Unscrew the battery compartment’s screws located on the silver reflector and remove the compartment doors.
4. Unclip the battery connectors and remove the old batteries. Make sure the new batteries are high quality – 2 Li-Ion Battery packs (3.2 Volt / 1500 mAh) with matching connector.
5. Install the new batteries into the battery compartment.
6. Reassemble the unit by reversing the above procedure.



Batteries are available for purchase at www.gamasonic.com

WARNING: Do not dispose of Li-Ion batteries in the regular trash, municipal waste stream or by fire as batteries may leak or explode. Do not open, short circuit, or mutilate batteries as injury may occur. Preserve our environment by recycling Li-Ion batteries or disposing of them in accordance with local, State, and federal regulations. Do not mix old and new batteries.

Maintenance

Clean the solar panels regularly with a damp towel to guarantee optimum performance. Do not use any type of solvent for cleaning and be careful not to put too much pressure on the solar panels while cleaning.

Troubleshooting

If your solar light does not come on as expected despite observance of all the instructions, please try the following steps:

1. Make sure that the solar lamp is not being affected by any other light source.
2. Ensure the solar lamp is not positioned in the shade during the day.
3. Check that the batteries are installed correctly.

NOTE: The performance of the solar lamp will vary with the time of year. It will last longer when it has had a full day in the sun rather than a day in overcast weather.



WINTERTIME TIPS: For optimal performance, be sure to remove any snow or debris accumulation from solar panel(s). A solar panel free of debris will charge the batteries much more efficiently.

WARNING: Please keep out of reach of children. Do not dispose of the Li-Ion battery in the regular trash, municipal waste stream or by fire as batteries may leak or explode. Do not open, short circuit, or mutilate batteries as injury may occur. Preserve our environment by recycling Li-Ion batteries or disposing of them in accordance with local, State and federal regulations. Do not mix old and new batteries.

